

Installing 64-bit Drivers with Torchmate 3.0.19 in Windows Vista/7 x64

1. Install Torchmate Driver Software.
2. Plug in the signal generator; the driver will fail to install.
3. Unzip the 64-bit drivers into a new folder, such as "C:\64-bit CNC drivers."
4. Click Start → Control Panel.
5. Switch to classic view:
 - a. Windows Vista: In the top left corner of the window, click "Classic View."
 - b. Windows 7: In the top right corner of the window, click "View By" and select either "Large Icons" or "Small Icons."
6. Open the Device Manager.
7. Expand the "Universal Serial Bus controllers" listing.
8. Right-click on "USB Signal Generator 501A" and select "Update drivers..."
9. Choose to browse manually, and locate the folder containing the 64-bit drivers.
10. Click OK. The signal generator should now work!